

MLA-55 Rotor



**Used In Beckman Coulter
Optima™ MAX, MAX-XP,
and MAX-E
Tabletop Ultracentrifuges**



SAFETY NOTICE

This safety notice summarizes information basic to the safe use of the rotor described in this manual. The international symbol displayed above is a reminder to the user that all safety instructions should be read and understood before operation or maintenance of this equipment is attempted. When you see the symbol on other pages throughout this publication, pay special attention to the specific safety information presented. Observance of safety precautions will also help to avoid actions that could damage or adversely affect the performance of the rotor. This rotor was developed, manufactured, and tested for safety and reliability as part of a Beckman Coulter ultracentrifuge/rotor system. Its safety or reliability cannot be assured if used in a centrifuge not of Beckman Coulter's manufacture or in a Beckman Coulter ultracentrifuge that has been modified without Beckman Coulter's approval.



Handle body fluids with care because they can transmit disease. No known test offers complete assurance that such fluids are free of micro-organisms. Some of the most virulent—Hepatitis (B and C) viruses, HIV (I–V), atypical mycobacteria, and certain systemic fungi—further emphasize the need for aerosol protection. Handle other infectious samples according to good laboratory procedures and methods to prevent spread of disease. Because spills may generate aerosols, observe proper safety precautions for aerosol containment. Do not run toxic, pathogenic, or radioactive materials in this rotor without taking appropriate safety precautions. Biosafe containment should be used when Risk Group II materials (as identified in the World Health Organization *Laboratory Biosafety Manual*) are handled; materials of a higher group require more than one level of protection.



The rotor and accessories are not designed for use with materials capable of developing flammable or explosive vapors. Do not centrifuge such materials in nor handle or store them near the ultracentrifuge.



Although rotor components and accessories made by other manufacturers may fit in the MLA-55 rotor, their safety in this rotor cannot be ascertained by Beckman Coulter. Use of other manufacturers' components or accessories in the MLA-55 rotor may void the rotor warranty and should be prohibited by your laboratory safety officer. Only the components and accessories listed in this publication should be used in this rotor.



Make sure that filled containers are loaded symmetrically into the rotor and that opposing tubes are filled to the same level with liquid of the same density. Make sure that cavities in use have the proper spacers and/or floating spacers inserted before installing the rotor lid.



If disassembly reveals evidence of leakage, you should assume that some fluid escaped the rotor. Apply appropriate decontamination procedures to the centrifuge and accessories.




Never exceed the maximum rated speed of the rotor and labware in use. Refer to the section on RUN SPEEDS, and derate the run speed as appropriate.



Do not use sharp tools on the rotor that could cause scratches in the rotor surface. Corrosion begins in scratches and may open fissures in the rotor with continued use.

MLA-55 ROTOR



SPECIFICATIONS

Maximum speed	55 000 rpm
Density rating at maximum speed	1.2 g/mL
Relative Centrifugal Field* at maximum speed	
At r_{max} (84.5 mm)	$287\,000 \times g$
At r_{av} (64.0 mm)	$217\,000 \times g$
At r_{min} (45.0 mm)	$151\,000 \times g$
k factor at maximum speed	53
Conditions requiring speed reductions	see RUN SPEEDS
Number of tube cavities	8
Available tubes	see Table 1
Nominal tube dimensions (largest tube)	16×76 mm
Nominal tube capacity (largest tube)	13.5 mL
Nominal rotor capacity	108 mL
Approximate acceleration time to maximum	
speed (fully loaded)	15 min
Approximate deceleration time from maximum	
speed (fully loaded)	5 min
Weight of fully loaded rotor	2.45 kg (5.4 lb)
Rotor and lid material	aluminum


*Relative Centrifugal Field (RCF) is the ratio of the centrifugal acceleration at a specified radius and speed ($r\omega^2$) to the standard acceleration of gravity (g) according to the following formula:

$$RCF = \frac{r\omega^2}{g}$$

where r is the radius in millimeters, ω is the angular velocity in radians per second ($2\pi \text{RPM}/60$), and g is the standard acceleration of gravity (9807 mm/s^2). After substitution:

$$RCF = 1.12 r \left(\frac{\text{RPM}}{1000} \right)^2$$

DESCRIPTION



This Beckman Coulter rotor has been manufactured in an ISO 9001 or 13485 facility for use with the specified Beckman Coulter ultracentrifuges.

The MLA-55 fixed angle rotor, rated for 55 000 rpm, has a tube angle of 35 degrees from the axis of rotation. The rotor can centrifuge up to eight tubes and is used in Beckman Coulter Optima™ MAX, MAX-XP, and MAX-E tabletop ultracentrifuges.

The rotor, lid, and handle are made of aluminum and anodized to resist corrosion. A rotor retention mechanism on the ultracentrifuge drive hub secures the rotor during the run. Lubricated O-rings made of Buna-N rubber in the rotor lid and handle maintain atmospheric pressure inside the rotor during centrifugation. The tube cavities are numbered to aid in sample identification.

The ultracentrifuge identifies rotor speed during the run by means of a magnetic speed sensor in the instrument chamber and magnets on the bottom of the rotor. This overspeed protection system ensures that the rotor does not exceed its maximum permitted speed.

See the Warranty at the back of this manual for warranty information.

PREPARATION AND USE

Specific information about the MLA-55 rotor is given here. Information common to this and other rotors is contained in Rotors and Tubes for Tabletop Preparative Ultracentrifuges (publication TLR-IM), which should be used together with this manual for complete rotor and accessory operation. Publication TLR-IM is included in the literature package shipped with the rotor.

NOTE

Although rotor components and accessories made by other manufacturers may fit in the MLA-55 rotor, their safety in this rotor cannot be ascertained by Beckman Coulter. Use of other manufacturers' components or accessories in the MLA-55 rotor may void the rotor warranty and should be prohibited by your laboratory safety officer. Only the components and accessories listed in this publication should be used in this rotor.

PRERUN SAFETY CHECKS




Read the Safety Notice page at the front of this manual before using the rotor.

1. Inspect the rotor assembly (rotor, lid, handle, and O-rings) for damage—the high forces generated in this rotor can cause damaged components to fail.
2. Make sure to use only tubes and accessories listed in Table 1.
3. Check the chemical compatibilities of all materials used (refer to Appendix A in *Rotors and Tubes*).

ROTOR PREPARATION

For runs at other than room temperature, refrigerate or warm the rotor beforehand for fast equilibration.



1. Lightly but evenly lubricate metal threads with Spinkote™ lubricant (306812).
2. Apply a thin film of silicone vacuum grease (335148) to the O-rings in the rotor lid and handle.
4. Load the filled and sealed (if applicable) tubes symmetrically into the rotor (see page 7 for tube information). If fewer than eight tubes are being run, they must be arranged symmetrically in the rotor (see Figure 1). *Opposing tubes must be filled to the same level with liquid of the same density.*
5. Use the required spacers, if necessary (see Table 1), to complete the loading operation.




Figure 1. Arranging Tubes in the Rotor. Two, four, six, or eight tubes can be centrifuged per run if they are arranged in the rotor as shown.

6. After the rotor is loaded, insert it into the square metal rotor vise (347373). Place the lid on the rotor. Place the handle on the rotor and tighten it firmly to the right (clockwise) by hand. No tool is required.



CAUTION

Before each run, make sure that the handle is securely tightened.

OPERATION

1. Use an absorbent towel to wipe off condensation from the rotor.
2. Carefully place the rotor on the drive hub.
3. Refer to the instrument instruction manual for ultracentrifuge operation.
4. For additional operating information, see the following:
 - RUN TIMES, page 12, for using k factors to adjust run durations.
 - RUN SPEEDS, page 13, for information about speed limitations.
 - SELECTING CsCl GRADIENTS, page 15, for methods to avoid CsCl precipitation during centrifugation.

REMOVAL AND SAMPLE RECOVERY




CAUTION

If disassembly reveals evidence of leakage, you should assume that some fluid escaped the rotor. Apply appropriate decontamination procedures to the centrifuge and accessories.

1. Remove the rotor from the ultracentrifuge and place it in the rotor vise.
2. Remove the handle by unscrewing it to the left (counterclockwise). Remove the lid.
3. Use a tube removal tool to remove the spacers and tubes.

TUBES AND ACCESSORIES


The MLA-55 rotor uses tubes and accessories listed in Table 1. Be sure to use only those items listed, and to observe the maximum speed limits shown. Refer to Appendix A in *Rotors and Tubes* for information on the chemical resistances of tube and accessory materials.



Temperature Limits

- Plastic tubes have been centrifuge tested for use at temperatures between 2 and 25°C. For centrifugation at other temperatures, pretest tubes under anticipated run conditions.
- If plastic containers are frozen before use, make sure that they are thawed to at least 2°C prior to centrifugation.

OptiSeal™ Tubes



OptiSeal tubes come with plastic plugs and can be quickly and easily prepared for use. With the tube spacer in place, the g force during centrifugation ensures a tight, reliable seal that protects your samples.

- Place the tubes in the rack and fill each tube to the base of the stem, leaving no fluid in the stem. Overfilling the tube can cause spillage when the plug is inserted or can compromise seal integrity. However, too much air can cause excessive tube deformation, disrupting gradients and sample bands.
- Refer to *Using OptiSeal™ Tubes* (publication IN-189), included in each box of tubes, for detailed information on the use and care of OptiSeal tubes.

Table 1. Available Tubes for the MLA-55 Rotor.
Use only the items listed here and observe maximum fill volumes and speeds shown.

Tube			Required Accessory		Tube Rack	Max Speed/ RCF/ k Factor
Dimensions/ Nominal Volume/ Max Fill Volume	Description	Part Number	Description	Part Number		
16 × 76 mm 13.5 mL 13.1 mL	Quick-Seal® Ultra-Clear™	344322 (pkg/50)	red aluminum spacer	342695	348123 ^a	55 000 rpm 289 674 × g 74
16 × 76 mm 13.5 mL 12.3 mL	Quick-Seal polyallomer	342413 (pkg/50)	red aluminum spacer	342695	348123 ^a	55 000 rpm 289 335 × g 77
16 × 76 mm 13.5 mL 12.1 mL	Ultra-Clear	344085 (pkg/50)	titanium cap (use the red silicone O-ring)	341968	none	55 000 rpm 291 029 × g 61
16 × 76 mm 13.5 mL 12.1 mL	thinwall polyallomer	326814 (pkg/50)	titanium cap (use the black Buna N O-ring)	341968	none	55 000 rpm 289 335 × g 59
16 × 76 mm 10.0 mL 8.6 mL	thickwall polyallomer	355640 (pkg/25)	aluminum cap	338907	none	30 000 rpm 85 176 × g 177
16 × 76 mm 10.0 mL 8.6 mL	thickwall polycarbonate	355630 (pkg/25)	aluminum cap	338907	none	55 000 rpm 286 286 × g 53
16 × 76 mm 10.4 mL 10.0 mL	polycarbonate bottle assembly (bottle only— 355651)	355603 (pkg/6)	Noryl ^c cap	355604	none	55 000 rpm 288 658 × g 67
16 × 67 mm 10.0 mL 10.6 mL	Quick-Seal polyallomer	344622 (pkg/50)	Noryl spacer	344676	348123 ^d	55 000 rpm 289 335 × g 60
16 × 60 mm 8.9 mL 8.9 mL	OptiSeal bell-top ^e	361623 (pkg/56)	amber Ultem ^f spacer	361670 (pkg/2)	361642	55 000 rpm 289 996 × g 52

^a Tube Topper™ rack; if using the older tabletop tube sealer, use tube rack 342488.

— continued

^b Max speeds given are those that the tubes could withstand when tested at 25°C for 24 hours.

^c Noryl is a registered trademark of GE Plastics.

^d Tube Topper rack, if using the older tabletop tube sealer, use rack 344641.

^e Includes disposable plastic plugs.

^f Ultem is a registered trademark of GE Plastics.

^g Delrin is a registered trademark of E.I. Du Pont de Nemours & Company.

^h Cap assembly includes neoprene gasket (344672) and stem (346246).

ⁱ Tube Topper rack; if using the older tabletop tube sealer, use rack 344641 and use spacer (345828) upside-down in the bottom of the tube rack before inserting a tube (to remove the spacers, turn the rack upside-down).

Table 1. Available Tubes for the MLA-55 Rotor (continued).
Use only the items listed here and observe maximum fill volumes and speeds shown.

Tube			Required Accessory		Tube Rack	Max Speed/ RCF/ k Factor
Dimensions/ Nominal Volume/ Max Fill Volume	Description	Part Number	Description	Part Number		
13 × 64 mm 6.5 mL 5.8 mL	Ultra-Clear	344088 (pkg/50)	Delrin ^g adapter	303313	none	50 000 rpm 215 600 × g 57
			aluminum cap	346256 ^h		
16 × 64 mm 6.5 mL 5.8 mL	thinwall polyallomer	326820 (pkg/50)	Delrin adapter	303313	none	50 000 rpm 215 880 × g 56
			aluminum cap	346256 ^h		
16 × 45 mm 6.3 mL 6.7 mL	Quick-Seal polyallomer	345830 (pkg/50)	Noryl floating spacer	345828	348123 ⁱ	55 000 rpm 289 335 × g 37
16 × 45 mm 6.3 mL 6.7 mL	Quick-Seal polyallomer	357334 (pkg/50)	Noryl floating spacer	345828	348123 ⁱ	55 000 rpm 289 335 × g 37
16 × 38 mm 4.2 mL 4.8 mL	Quick-Seal polyallomer	356562 (pkg/50)	Noryl floating spacer	345828	348123 ^a	55 000 rpm 289 335 × g 28
16 × 38 mm 4.2 mL 4.8 mL	Quick-Seal polyallomer	357332 (pkg/50)	Noryl floating spacer	345828	348123 ^a	55 000 rpm 289 335 × g 28
13 × 64 mm 4.0 mL 4.2 mL	thickwall polyallomer	355644 (pkg/25)	Delrin adapter	303313	none	50 000 rpm 214 200 × g 52
13 × 64 mm 4.0 mL 4.2 mL	thickwall polycarbonate	355645 (pkg/25)	Delrin adapter	303313	none	50 000 rpm ^b 214 200 × g 52
13 × 41 mm 4.0 mL 3.6 mL	Ultra-Clear	344093 (pkg/50)	Delrin adapter	303402	none	45 000 rpm 145 379 × g 53
			aluminum cap	346256 ^h		

^a Tube Topper™ rack; if using the older tabletop tube sealer, use tube rack 342488.

— continued

^b Max speeds given are those that the tubes could withstand when tested at 25°C for 24 hours.

^c Noryl is a registered trademark of GE Plastics.

^d Tube Topper rack, if using the older tabletop tube sealer, use rack 344641.

^e Includes disposable plastic plugs.

^f Ultem is a registered trademark of GE Plastics.

^g Delrin is a registered trademark of E.I. Du Pont de Nemours & Company.

^h Cap assembly includes neoprene gasket (344672) and stem (346246).

ⁱ Tube Topper rack; if using the older tabletop tube sealer, use rack 344641 and use spacer (345828) upside-down in the bottom of the tube rack before inserting a tube (to remove the spacers, turn the rack upside-down).

Table 1. Available Tubes for the MLA-55 Rotor (continued).
Use only the items listed here and observe maximum fill volumes and speeds shown.

Tube			Required Accessory		Tube Rack	Max Speed/ RCF/ k Factor
Dimensions/ Nominal Volume/ Max Fill Volume	Description	Part Number	Description	Part Number		
13 × 32 mm 3.0 mL 2.2 mL	Ultra-Clear	344092 (pkg/50)	Delrin adapter	303401	none	45 000 rpm 133 585 × g 37
			aluminum cap	346256 ⁱ		
8 × 49 mm 2.0 mL 2.0 mL	Ultra-Clear	344091 (pkg/50)	Delrin adapter	303376	none	40 000 rpm 143 718 × g 80
			aluminum cap	303624		

^a Tube Topper™ rack; if using the older tabletop tube sealer, use tube rack 342488.

^b Max speeds given are those that the tubes could withstand when tested at 25°C for 24 hours.

^c Noryl is a registered trademark of GE Plastics.

^d Tube Topper rack, if using the older tabletop tube sealer, use rack 344641.

^e Includes disposable plastic plugs.

^f Ultem is a registered trademark of GE Plastics.

^g Delrin is a registered trademark of E.I. Du Pont de Nemours & Company.

^h Cap assembly includes neoprene gasket (344672) and stem (346246).

ⁱ Tube Topper rack; if using the older tabletop tube sealer, use rack 344641 and use spacer (345828) upside-down in the bottom of the tube rack before inserting a tube (to remove the spacers, turn the rack upside-down).

Quick-Seal® Tubes



Quick-Seal tubes must be sealed prior to centrifugation. These tubes are heat sealed and do not need caps; however, spacers are required on top of the tubes when they are loaded into the rotor.

- Fill Quick-Seal tubes leaving a *small* bubble of air at the base of the neck. Do not leave a large air space—too much air can cause excessive tube deformation.
- Refer to *Rotors and Tubes* for detailed information on the use and care of Quick-Seal tubes.

Some of the tubes listed in Table 1 are part of the g-Max™ system. The g-Max system uses a combination of small bell-top Quick-Seal tubes and floating spacers (also called g-Max spacers). This means that you can run the shorter tubes listed in the table in the MLA-55 rotor without reduction in g force. Additional information about the g-Max system is available in publication DS-709.




Thinwall Tubes

Thinwall polyallomer and Ultra-Clear tubes require caps for tube support. Fill the tubes as full as possible to prevent tube collapse during centrifugation. If necessary, float mineral oil (or some other low-density, immiscible liquid) on top of the tube contents to fill the tube to its maximum volume. (Do not use an oil overlay in Ultra-Clear tubes.)




Thickwall Tubes

Thickwall polyallomer and polycarbonate tubes can be run partially filled (at least half filled) with or without caps, but all opposing tubes for a run must be filled to the same level with liquid of the same density. Do not overfill capless tubes; be sure to note the reductions in fill volume and run speed shown in Table 1.



Tube Caps

Thinwall tubes require caps for tube support during centrifugation; thickwall tubes and bottles can be run with or without caps (speed reduction may be required). Use only the caps listed in Table 1. Refer to *Rotors and Tubes* for the use, assembly, and maintenance of caps.




- Inspect tube caps before use as described in *Rotors and Tubes*. Replace any damaged components.
- Inspect the O-rings or gaskets in the caps for cracks, nicks, or flattened areas. Be sure that they are dry and free of lubricant during assembly.
- Tighten caps with a torque wrench to 11 N•M (100 in.-lb) while the tube is held in the tube-cap vise (305075).
- Tighten bottle caps by hand.



Polycarbonate Bottles

The polycarbonate bottles may be centrifuged completely filled, or partially filled (not less than half full). Again, all opposing containers for a run must be filled to the same level. Be sure to note the reductions in run speed shown in Table 1 if bottles are partially filled.

RUN TIMES



The k factor of the rotor is a measure of the rotor's pelleting efficiency. (Beckman Coulter has calculated the k factors for all of its preparative rotors at maximum rated speed and using full tubes.¹) The k factor is calculated from the formula:

$$k = \frac{\ln(r_{\max}/r_{\min})}{\omega^2} \times \frac{10^{13}}{3600} \quad (1)$$

where ω is the angular velocity of the rotor in radians per second ($\omega = 0.105 \times \text{rpm}$), r_{\max} is the maximum radius, and r_{\min} is the minimum radius.

After substitution:

$$k = \frac{(2.533 \times 10^{11}) \ln(r_{\max}/r_{\min})}{\text{rpm}^2} \quad (2)$$

Use the k factor in the following equation to estimate the run time t (in hours) required to pellet particles of known sedimentation coefficient s (in Svedberg units, S).

$$t = \frac{k}{s} \quad (3)$$

Run times can be estimated for centrifugation at less than maximum speed by adjusting the k factor as follows:

$$k_{\text{adj}} = k \left(\frac{55\,000}{\text{actual run speed}} \right)^2 \quad (4)$$


¹ For the MLA-55 rotor, the k factor was calculated using the maximum volume allowed in a 10-mL open top tube.

Run times can also be estimated from data established in prior experiments if the k factor of the previous rotor is known. For any two rotors, a and b:

$$\frac{t_a}{t_b} = \frac{k_a}{k_b} \quad (5)$$

For more information on k factors see *Use of k Factor for Estimating Run Times from Previously Established Run Conditions* (publication DS-719).

RUN SPEEDS



The centrifugal force at a given radius in a rotor is a function of speed. Comparisons of forces between different rotors are made by comparing the rotors' relative centrifugal fields (RCF). When rotational speed is adjusted so that identical samples are subjected to the same RCF in two different rotors, the samples are subjected to the same force. The RCF at a number of rotor speeds is provided in Table 2.

Speeds must be reduced under the following circumstances:

1. If nonprecipitating solutions more dense than 1.2 g/mL are centrifuged, the maximum allowable run speed must be reduced according to the following equation:

$$\text{reduced maximum speed} = (55\,000 \text{ rpm}) \sqrt{\frac{1.2 \text{ g/mL}}{\rho}} \quad (6)$$


where ρ is the density of the tube contents. This speed reduction will protect the rotor from excessive stresses due to the added tube load. *Note, however, that the use of this formula may still produce maximum speed values that are higher than the limitations imposed by the use of certain tubes or adapters.* In such cases, use the lower of the two values.

2. *Further speed limits must be imposed* when CsCl or other self-forming-gradient salts are centrifuged, as equation (6) does not predict concentration limits/speeds that are required to avoid precipitation of salt crystals. Precipitation during centrifugation would alter the density distribution of CsCl and this would change the position of the sample bands. Figures 2 and 3, together with the description and examples below, show how to reduce run speeds when using CsCl gradients.

Table 2. Relative Centrifugal Fields for the MLA-55 Rotor.
 Entries in this table are calculated from the formula
 $RCF = 1.12r (RPM/1000)^2$ and then rounded to three significant digits.

Rotor Speed (rpm)	Relative Centrifugal Field ($\times g$)			k Factor*
	At r_{max} (84.6 mm)	At r_{av} (64.0 mm)	At r_{min} (44.6 mm)	
55 000	287 000	217 000	151 000	54
50 000	237 000	179 000	125 000	65
45 000	192 000	145 000	101 000	80
40 000	152 000	115 000	79 900	101
35 000	116 000	87 800	61 200	132
30 000	85 300	64 500	45 000	180
25 000	59 200	44 800	31 200	259
20 000	37 900	28 700	19 000	405
15 000	21 300	161 000	11 200	721
10 000	9 475	7 168	4 995	1 622
5 000	2 369	1 792	1 249	6 487

*Calculated for all Beckman Coulter preparative rotors as a measure of the rotor's relative efficiency in pelleting sample in water at 20°C.



SELECTING CsCl GRADIENTS



Precipitation during centrifugation would alter density distribution, and this would change the position of the sample bands. Curves in Figures 2 and 3 are provided up to the maximum rated speed of the rotor.

NOTE

The curves in Figures 2 and 3 are for solutions of CsCl salt dissolved in distilled water only. If other salts are present in significant concentrations, the overall CsCl concentration may need to be reduced.

Rotor speed is used to control the slope of a CsCl density gradient, and must be limited so that CsCl precipitation is avoided. Speed and density combinations that intersect on or below the curves in Figure 2 ensure that CsCl will not precipitate during centrifugation in the MLA-55 rotor. Curves are provided at two temperatures: 20°C (black curves) and 4°C (gray curves).

The reference curves in Figure 3 show gradient distribution at equilibrium. Each curve in Figure 3 is within the density limits allowed for the MLA-55 rotor: each curve was generated for a single run speed using the maximum allowable homogeneous CsCl densities (one for each fill level) that avoid precipitation at that speed. (The gradients in Figure 3 can be generated from step or linear gradients, or from homogeneous solutions. But the total amount of CsCl in solution must be equivalent to a homogeneous solution corresponding to the concentrations specified in Figure 2.) Figure 3 can also be used to approximate the banding positions of sample particles. Gradient curves not shown in Figure 3 can be interpolated.

TYPICAL EXAMPLES FOR DETERMINING CsCl RUN PARAMETERS

Example A: A separation that is done frequently is the banding of plasmic DNA in cesium chloride with ethidium bromide. The starting density of the CsCl solution is 1.55 g/mL. In this separation the covalently closed, circular plasmid bands at a density of 1.57 g/mL, while the nicked and linear species band at 1.53 g/mL. At 20°C, where will particles band?




Figure 2. Precipitation Curves for the MLA-55 Rotor. Using combinations of rotor speeds and homogeneous CsCl solution densities that intersect on or below these curves ensures that CsCl will not precipitate during centrifugation.







Figure 3. CsCl Gradients at Equilibrium for the MLA-55 Rotor. Centrifugation of homogeneous CsCl solutions at the maximum allowable speeds (from Figure 2) results in gradients presented here.



1. In Figure 2, find the curve that corresponds to the desired run temperature (20°C) and fill volume (full). The maximum allowable rotor speed is determined from the point where this curve intersects the homogeneous CsCl density (43 000 rpm).
2. In Figure 3, sketch in a horizontal line corresponding to each particle's buoyant density.
3. Mark the point in the figure where each particle density intersects the curve corresponding to the selected run speed and temperature.
4. Particles will band at these locations across the tube diameter at equilibrium during centrifugation.

In this example, particles will band about 63.1 and 61.1 mm from the axis of rotation, about 2.0 mm of center-of-band to center-of-band separation at the rotor's 35-degree tube angle. When the tube is held upright, there will be about 2.4 mm of center-of-band to center-of-band separation. This interband distance, d_{up} , can be calculated from the formula:

$$d_{up} = \frac{d_{\theta}}{\cos \theta} \tag{7}$$

where d_{θ} is the interband distance when the tube is held at an angle, θ , in the rotor.

Example B: Knowing particle buoyant densities (such as 1.59 and 1.54 g/mL), how do you achieve good separation?

1. In Figure 3, sketch in a horizontal line corresponding to each particle's buoyant density.
2. Select the curve at the desired temperature (20°C) that gives the best particle separation.
3. Note the run speed along the selected curve (35 000 rpm).
4. From Figure 2, select the maximum homogeneous CsCl density (in this case, 1.65 g/mL) that corresponds to the temperature and run speed established above. These parameters will provide the particle-banding pattern selected in Step 2.


In this example, particles will band at about 48.4 and 57.9 mm from the axis of rotation (about 9.5 mm apart). When the tube is held upright there will be about 11.6 mm of center-of-band to center-of-band separation.

CARE AND MAINTENANCE

MAINTENANCE

NOTE

Do not use sharp tools on the rotor that could cause scratches in the rotor surface. Corrosion begins in scratches and may open fissures in the rotor with continued use.



- Periodically (at least monthly) inspect the rotor, specially inside cavities, for rough spots or pitting, white powder deposits (which may be aluminum oxide), or heavy discoloration. If any of these signs are evident, do not run the rotor. Contact your Beckman Coulter representative for information about the Field Rotor Inspection Program and the rotor repair center.
- Regularly lubricate the metal threads in the rotor with a thin, even coat of Spinkote lubricant (306812). Failure to keep these threads lubricated can result in damaged threads.
- Regularly apply silicone vacuum grease to the O-rings. Replace the O-rings about twice a year or whenever worn or damaged.

Refer to Appendix A in *Rotors and Tubes* for the chemical resistances of rotor and accessory materials. Your Beckman Coulter representative provides contact with the Field Rotor Inspection Program and the rotor repair center.

CLEANING



Wash the rotor and rotor components immediately if salts or other corrosive materials are used or if spillage has occurred. Do not allow corrosive materials to dry on the rotor.


Under normal use, wash the rotor frequently (at least weekly) to prevent buildup of residues.

1. Remove the O-rings before washing.
2. Wash the rotor and lid in a mild detergent, such as Beckman Solution 555™ (339555), that won't damage the rotor. The Rotor Cleaning Kit contains two plastic-coated brushes and two quarts

of Solution 555 for use with rotors and accessories. Dilute the detergent 10 to 1 with water.

NOTE

Do not wash rotor components in a dishwasher. Do not soak in detergent solution for long periods, such as overnight.



3. Rinse the cleaned rotor and components with distilled water.
4. Air-dry the rotor and lid upside down. *Do not use acetone to dry the rotor.*
5. Apply a thin, even coat of silicone vacuum grease to the O-rings before replacing them in the grooves in the lid and handle.

Clean metal threads as necessary (at least every 6 months). Use a brush and concentrated Solution 555. Rinse and dry thoroughly, then lubricate lightly but evenly with Spinkote to coat all threads.

Periodically remove the O-rings and wipe clean as necessary. Clean the O-ring grooves with a cotton-tipped swab. Reapply a light film of silicone vacuum grease.

DECONTAMINATION



If the rotor (and/or accessories) becomes contaminated with radioactive material, it should be decontaminated using a solution that will not damage the anodized surfaces. Beckman Coulter has tested a number of solutions and found two that do not harm anodized aluminum: RadCon Surface Spray or IsoClean Solution (for soaking),² and Radiacwash.³

NOTE

IsoClean can cause fading of colored anodized surfaces. Use it only when necessary and remove it promptly from surfaces.

² In U.S., contact Nuclear Associates (New York); in Eastern Europe and Commonwealth States, contact Victoreen GmbH (Munich); in South Pacific, contact Gammasonics Pty. Ltd. (Australia); in Japan, contact Toyo Medic Co. Ltd. (Tokyo).


³ In U.S., contact Biodex Medical Systems (Shirley, New York); internationally, contact the U.S. office to find the dealer closest to you.

While Beckman Coulter has tested these methods and found that they do not damage components, no guarantee of decontamination is expressed or implied. Consult your laboratory safety officer regarding the proper decontamination methods to use.



If the rotor or other components are contaminated with toxic or pathogenic materials, follow appropriate decontamination procedures as outlined by your laboratory safety officer.

STERILIZATION AND DISINFECTION



- The rotor and all rotor components can be autoclaved at 121°C for up to an hour. Remove the O-rings from the handle and lid and place the rotor, handle, and lid in the autoclave upside down.
- Ethanol (70%)⁴ or hydrogen peroxide (6%) may be used on all rotor components, including those made of plastic. Bleach (sodium hypochlorite) may be used, but may cause discoloration of anodized surfaces. Use the minimum immersion time for each solution, per laboratory standards.


While Beckman Coulter has tested these methods and found that they do not damage the rotor or components, no guarantee of sterility or disinfection is expressed or implied. When sterilization or disinfection is a concern, consult your laboratory safety officer regarding proper methods to use.

STORAGE

When it is not in use, store the rotor in a dry environment (not in the instrument) with the lid removed to allow air circulation so moisture will not collect in the tube cavities.

⁴ Flammability hazard. Do not use in or near operating ultracentrifuges.

RETURNING A ROTOR



Before returning a rotor or accessory for any reason, prior permission (a Returned Goods Authorization form) must be obtained from Beckman Coulter, Inc. This RGA form may be obtained from your local Beckman Coulter sales office, and should contain the following information:

- serial number,
- history of use (approximate frequency of use),
- reason for the return,
- original purchase order number, billing number, and shipping number, if possible,
- name and phone number of the person to be notified upon receipt of the rotor or accessory at the factory,
- name and phone number of the person to be notified about repair costs, etc.

To protect our personnel, it is the customer's responsibility to ensure that all parts are free from pathogens and/or radioactivity. Sterilization and decontamination must be done before returning the parts. Smaller items (such as tubes, bottles, etc.) should be enclosed in a sealed plastic bag.

*All parts must be accompanied by a note, plainly visible on the outside of the box or bag, stating that they are safe to handle and that they are not contaminated with pathogens or radioactivity. **Failure to attach this notification will result in return or disposal of the items without review of the reported problem.***

Use the address label printed on the RGA form when mailing the rotor and/or accessories to:

Beckman Coulter, Inc.
1050 Page Mill Road
Palo Alto, CA 94304
Attention: Returned Goods

Customers located outside the United States should contact their local Beckman Coulter office.

SUPPLY LIST

NOTE

Publications referenced in this manual can be obtained by calling Beckman Coulter at 1-800-742-2345 in the United States, or by contacting your local Beckman Coulter office.

See the Beckman Coulter *Ultracentrifuge Rotors, Tubes & Accessories* catalog (BR-8101, available at www.beckmancoulter.com) or contact Beckman Coulter Sales (1-800-742-2345 in the United States; worldwide offices are listed on the back cover of this manual) for detailed information on ordering parts and supplies. For your convenience, a partial list is given below.

REPLACEMENT ROTOR PARTS

MLA-55 rotor assembly	393203
Handle	393206
Lid	393210
Handle O-ring (small)	839347
Lid O-ring (large)	876089
Rotor vise	347373

OTHER

Tubes, bottles, and accessories	see Table 1
OptiSeal tube rack assembly	361642
Quick-Seal Cordless Tube Topper kit, 60 Hz	358312
Quick-Seal Cordless Tube Topper kit, 50 Hz (Europe)	358313
Quick-Seal Cordless Tube Topper kit, 50 Hz (Great Britain)	358314
Quick-Seal Cordless Tube Topper kit, 50 Hz (Australia)	358315
Quick-Seal Cordless Tube Topper kit, 50 Hz (Canada)	367803
Tube Topper rack	348123
Tool kit for aluminum caps	331202
includes:	
Torque wrench	858121
Socket adapter	858122
Socket for 11-mm hex nuts	870432
Tube removal tool	301875
Hex driver (for 11-mm cap nuts on stainless steel tubes)	841883
Floating spacer removal tool	338765
Tube-cap vise	305075
Tube removal tool (Quick-Seal and OptiSeal tubes)	361668
Spinkote lubricant (2 oz)	306812
Silicone vacuum grease (1 oz)	335148

Rotor Cleaning Kit	339558
Beckman Solution 555 (1 qt)	339555
Rotor cleaning brush.....	339379

ULTRACENTRIFUGE ROTOR WARRANTY

All Beckman Coulter ultracentrifuge Fixed Angle, Vertical Tube, Near Vertical Tube, Swinging Bucket, and Airfuge rotors are warranted against defects in materials or workmanship for the time periods indicated below, subject to the Warranty Conditions stated below.

Preparative Ultracentrifuge Rotors 5 years — No Proration

Analytical Ultracentrifuge Rotors 5 years — No Proration

ML and TL Series Ultracentrifuge

Rotors 5 years — No Proration

Airfuge Ultracentrifuge Rotors 1 year — No Proration

For Zonal, Continuous Flow, Component Test, and Rock Core ultracentrifuge rotors, see separate warranty.

Warranty Conditions (as applicable)

- 1) This warranty is valid for the time periods indicated above from the date of shipment to the original Buyer by Beckman Coulter or an authorized Beckman Coulter representative.
- 2) This warranty extends only to the original Buyer and may not be assigned or extended to a third person without written consent of Beckman Coulter.
- 3) This warranty covers the Beckman Coulter Centrifuge Systems only (including but not limited to the centrifuge, rotor, and accessories) and Beckman Coulter shall not be liable for damage to or loss of the user's sample, non-Beckman Coulter tubes, adapters, or other rotor contents.
- 4) This warranty is void if the Beckman Coulter Centrifuge System is determined by Beckman Coulter to have been operated or maintained in a manner contrary to the instructions in the operator's manual(s) for the Beckman Coulter Centrifuge System components in use. This includes but is not limited to operator misuse, abuse, or negligence regarding indicated maintenance procedures, centrifuge and rotor classification requirements, proper speed reduction for the high density of certain fluids, tubes, and tube caps, speed reduction for precipitating gradient materials, and speed reduction for high-temperature operation.
- 5) Rotor bucket sets purchased concurrently with or subsequent to the purchase of a Swinging Bucket Rotor are warranted only for a term co-extensive with that of the rotor for which the bucket sets are purchased.
- 6) This warranty does not cover the failure of a Beckman Coulter rotor in a centrifuge not of Beckman Coulter manufacture, or if the rotor is used in a Beckman Coulter centrifuge that has been modified without the written permission of Beckman Coulter, or is used with carriers, buckets, belts, or other devices not of Beckman Coulter manufacture.
- 7) Rotor parts subject to wear, including but not limited to rotor O-rings, VTi, NVT™, TLV, MLN, and TLN rotor tube cavity plugs and gaskets, tubing, tools, optical overspeed disks, bearings, seals, and lubrication are excluded from this warranty and should be frequently inspected and replaced if they become worn or damaged.
- 8) Keeping a rotor log is not mandatory, but may be desirable for maintenance of good laboratory practices.

Repair and Replacement Policies

- 1) If a Beckman Coulter rotor is determined by Beckman Coulter to be defective, Beckman Coulter will repair or replace it, subject to the Warranty Conditions. A replacement rotor will be warranted for the time remaining on the original rotor's warranty.
- 2) If a Beckman Coulter centrifuge is damaged due to a failure of a rotor covered by this warranty, Beckman Coulter will supply free of charge (i) all centrifuge parts required for repair (except the drive unit, which will be replaced at the then current price less a credit determined by the total number of revolutions or years completed, provided that such a unit was manufactured or rebuilt by Beckman Coulter), and (ii) if the centrifuge is currently covered by a Beckman Coulter warranty or Full Service Agreement, all labor necessary for repair of the centrifuge.
- 3) If a Beckman Coulter rotor covered by this warranty is damaged due to a malfunction of a Beckman Coulter ultracentrifuge covered by an Ultracentrifuge System Service Agreement, Beckman Coulter will repair or replace the rotor free of charge.
- 4) If a Beckman Coulter rotor covered by this warranty is damaged due to a failure of a Beckman Coulter tube, bottle, tube cap, spacer, or adapter, covered under the Conditions of this Warranty, Beckman Coulter will repair or replace the rotor and repair the instrument as per the conditions in policy point (2) above, and the replacement policy.
- 5) Damage to a Beckman Coulter rotor or instrument due to the failure or malfunction of a non-Beckman Coulter tube, bottle, tube cap, spacer, or adapter is not covered under this warranty, although Beckman Coulter will assist in seeking compensation under the manufacturer's warranty.

Disclaimer

IT IS EXPRESSLY AGREED THAT THE ABOVE WARRANTY SHALL BE IN LIEU OF ALL WARRANTIES OF FITNESS AND OF THE WARRANTY OF MERCHANTABILITY AND BECKMAN COULTER, INC. SHALL HAVE NO LIABILITY FOR SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND WHATSOEVER ARISING OUT OF THE MANUFACTURE, USE, SALE, HANDLING, REPAIR, MAINTENANCE, OR REPLACEMENT OF THE PRODUCT.

Factory Rotor Inspection Service

Beckman Coulter, Inc., will provide free mechanical and metallurgical inspection in Palo Alto, California, USA, of any Beckman Coulter rotor at the request of the user. (Shipping charges to Beckman Coulter are the responsibility of the user.) Rotors will be inspected in the user's laboratory if the centrifuge in which they are used is covered by an appropriate Beckman Coulter Service Agreement. Contact your local Beckman Coulter office for details of service coverage or cost.

Before shipping, contact the nearest Beckman Coulter Sales and Service office and request a Returned Goods Authorization (RGA) form and packaging instructions. Please include the complete rotor assembly, with buckets, lid, handle, tube cavity caps, etc. A SIGNED STATEMENT THAT THE ROTOR AND ACCESSORIES ARE NON-RADIOACTIVE, NON-PATHOGENIC, NON-TOXIC, AND OTHERWISE SAFE TO SHIP AND HANDLE IS REQUIRED.

Beckman Coulter Worldwide Biomedical Research Division Offices

AUSTRALIA

Beckman Coulter Australia Pty Ltd
Unit D, 24 College St.
Gladesville, NSW 2111
Australia
Telephone: (61) 2 9844-6000
or toll free: 1 800 060 880
Fax: (61) 2 9844-6096
email: lifescienceaustralia@beckman.com

CANADA

Beckman Coulter (Canada) Inc.
6755 Mississauga Road, Suite 600
Mississauga, Ontario
Canada L5N 7Y2
Telephone: (1) 905 819-1234
Fax: (1) 905 819-1485

CHINA

Beckman Coulter Inc.
Beijing Representative Office
Unit 2005A, 2006-2009, East Ocean Center
Jian Guomenwai Avenue
Beijing 100004
China
Telephone: (86) 10 6515 6028
Fax: (86) 10 6515 6025, 6515 6026

CZECH REPUBLIC

Beckman Coulter Prague
Radiova 1
102 27 Prague 10
Czech Republic
Telephone: (420) 267 00 85 13
Fax: (420) 267 00 83 23

EASTERN EUROPE/ MIDDLE EAST/NORTH AFRICA

Beckman Coulter International S.A.
22, Rue Juste-Olivier
Case Postale 301-303
CH-1260 Nyon, Switzerland
Telephone: (41) 22 365 3707
Fax: (41) 22 365 0700

FRANCE

Beckman Coulter France S.A.
Paris Nord II, 33/66 rue des Vanesses
B.P. 50359
Villepinte, France
95942 ROISSY CDG Cedex
Telephone: (33) 1 49 90 90 00
Fax: (33) 1 49 90 90 10
e-mail: bioresearch.france@beckman.com

GERMANY

Beckman Coulter GmbH
Europark Fichtenhain B-13
47807 Krefeld
Germany
Telephone: (49) 21 51 33 35
Fax: (49) 21 51 33 33
e-mail: bioresearch.de@beckman.com

HONG KONG

Beckman Coulter Hong Kong Ltd.
12th Floor, Oxford House
979 King's Road
Taikoo Place, Hong Kong
Telephone: (852) 2814 7431
Fax: (852) 2873 4511

INDIA

Beckman Coulter India Pvt. Ltd.
Solitaire Corporate Park
3rd Floor - Bldg. 11
Andheri Ghatkopar Link Road
Chakala, Andheri West
Mumbai India 400 098
Telephone: (91) 22 3080 5101

ITALY

Beckman Coulter S.p.a.
Centro Direzionale Lombardo
Palazzo F/1, Via Roma 108
20060 Cassina de' Pecchi
Milano, Italy
Telephone: (39) 02 953921
Fax: (39) 02 95392264

JAPAN

Beckman Coulter K.K.
TOC Ariake West Tower
2-5-7, Ariake, Koto-ku
Tokyo 135-0063 Japan
Telephone: (81) 3 5530 8500
Fax: (81) 3 5404 8436

MEXICO

Beckman Coulter de Mexico S.A. de C.V.
Avenida Popocatépetl #396
Colonia Gral. Pedro Maria Anaya
Codigo Postal 03340
Mexico, D.F. Mexico
Telephone: (001) 52-55-9183-2800

NETHERLANDS

Beckman Coulter Nederland B.V.
Nijverheidsweg 21
3641 RP-Mijdrecht
Postbus 47
3640 AA Mijdrecht
The Netherlands
Telephone: (31) 297-230630
Fax: (31) 297-288082

SINGAPORE

Beckman Coulter Singapore Pte. Ltd.
116 Changi Road
Unit #03-01/02
Singapore 419718
Telephone: (65) 6339 3633
Fax: (65) 6336 6303

SOUTH AFRICA/SUB-SAHARAN AFRICA

Beckman Coulter
Stand 1A Primegro Park
Tonetti Street
1685 Halfway House
Johannesburg
Republic of South Africa
Telephone: (27) 11-805-2014/5
Fax: (27) 11-805-4120
e-mail: beckman@intekom.co.za

SPAIN

Beckman Coulter España S.A.
C/ Caleruega, 81
28033 Madrid, Spain
Telephone: (34) 91 3836080
Fax: (34) 91 3836096
email: bioresearch.espana@beckman.com

SWEDEN

Beckman Coulter AB
Archimedesvaegen 7
Box 111 56
SE-168 11 Bromma
Sweden
Telephone: (46) 8 564 85 900
Telefax: (46) 8 564 85 901

SWITZERLAND

Beckman Coulter International S.A.
22, Rue Juste-Olivier
Case Postale 301-303
CH-1260 Nyon
Switzerland
Telephone: (41) 0800 850 810
Fax: (41) 0848 850 810

TAIWAN

Beckman Coulter Taiwan Inc.
Taiwan Branch
8th Floor
216 Tun Hwa South Road, Section 2
Taipei 106, Taiwan
Republic of China
Telephone: (886) 2 2378 3456
Fax: (886) 2 2377 0408

TURKEY

Beckman Coulter Ltd.
E-5 Yanyol Faith Cad.
81410 Soganklik Kartal
Istanbul
Turkey
Telephone: (90) 216 309 1900
Fax: (90) 216 309 0090

UNITED KINGDOM

Beckman Coulter United Kingdom Ltd
Oakley Court
Kingsmead Business Park
London Road
High Wycombe
Buckinghamshire HP11 1JU
England, U.K.
Telephone: (44) 01494 441181
Fax: (44) 01494 447558
e-mail: beckman_uk@beckman.com

*Additional addresses are available at
www.beckmancoulter.com.*



Beckman Coulter, Inc. • 4300 N. Harbor Boulevard, Box 3100 • Fullerton, California 92834-3100
Sales and Service: 1-800-742-2345 • Internet: www.beckmancoulter.com • Telex: 678413 • Fax: 1-800-643-4366

